SHDSL.bis

Up to 30Mbps

E1 / Ethernet



# FlexDSL Orion2



#### **Features**


- Up to 12/15Mbps Data Transmission per Copper Pair
- SHDSL and SHDSL.bis, TC-PAM16/32
- Additional TC-PAM4/8/64/128 Available
- 1, 2 or 4 Copper Pairs Support
- Ethernet Bridge (10/100BaseT)
- QoS and VLAN Support
- E1 (G.703/704, Balanced/Unbalanced)
- Multi-Service Operation
- Point-to-Point and Point-to-Multipoint Operation
- Console Port, Telnet, Web, SNMP Management
- 24/48VDC Powered, Low Power Consumption
- Included Primary Protection
- Robust DIN-Rail Metal Enclosure
- Industrial Temperature Range Available

The FlexDSL Orion2 SHDSL.bis product family offers a broad range of products, which are based on the latest SHDSL.bis standards (ITU-T G.991.2 & ETS TS 101524), while also being fully interoperable with all our existing SHDSL equipment (Orion1, Orion3 and MiniFlex). The FlexDSL Orion2 supports beside of the standardized TC-PAM16/32 also the new extended TC-PAM4/8/64/128 line coding with a software upgrade code. The support of these extended line codes ensures compatibility with existing SHDSL equipment, that is already installed, in order to protect customer investments, while at the same time providing an upgrade path to the newest DSL technologies.

SHDSL.bis allows symmetrical data and voice transmission at speeds up to 12/15Mbps over a single pair of copper. In addition, the FlexDSL Orion2 SHDSL.bis modem range also supports DSL channel bonding for up to 4 copper pairs! FlexDSL Orion2 SHDSL.bis modems can provide up to 2 complete E1 interfaces, which support framed and unframed services (G.703/704). An additional Ethernet port (10/100BaseT) ensures connectivity with bridge functionality. This makes FlexDSL Orion2 SHDSL.bis modems a perfect solution for a wide range of applications in which TDM and IP services need to be transmitted over copper wires.

Like all FlexDSL Orion products the FlexDSL Orion2 SHDSL.bis modems are based on industrial components and manufactured according to highest quality standards providing additional value due to the extended temperature ranges and higher reliability. The combination of comprehensive functions providing maximum flexibility together with the higher quality of the FlexDSL Orion2 SHDSL.bis product family make it the perfect choice for all your DSL needs.

## Possible Applications



#### **Quick Installation Guide**

#### **Enter an Orion2 Device**

You can use the Monitor (Local Craft Terminal, RS-232) interface with Hyper Terminal (or any equal program) or you can address the device with Telnet through the Ethernet interface.

Monitor (LCT, RS-232) Interface:

- Configure the COM port: Bits per second:9600, Data bits: 8, Parity: None, Stop bits: 1, Flow control: None
- Press < ENTER>.


Telnet through Ethernet Interface:

Type in command line <Telnet 192.168.0.235> and press <ENTER>. This is the default Ethernet Address for Orion2 devices.

After a successful entering the main menu of the device will be displayed.

#### Configure an Orion2 Device

A first installation example with the most important commands and points to care about is shown below. We just like to have an Ethernet transmission between the two devices over 2 SHDSL copper pairs with a speed of 11.4Mbit/s. The pairs should aggregate (bundle) the data traffic and in case of any SHDSL pair failure, the remaining pairs should continue to work.



Enter in device 1 with the Monitor (LCT, RS-232) or Telnet interface.

Type following commands	Description		
3 <,1>	Go to Configuration Management (CM)		
<default everything=""> &lt;↓&gt;</default>	Set everything to default configuration		
<master 1="" on=""> &lt;↓&gt;</master>	Configure SHDSL 1 as MASTER		
<master 2="" on=""> &lt;↓&gt;</master>	Configure SHDSL 2 as MASTER		
<payload 1="" wan=""> &lt;↓&gt;</payload>	Configure Ethernet over SHDSL 1		
<payload 2="" wan=""> &lt;↓&gt;</payload>	Configure Ethernet over SHDSL 2		
<net> &lt;, J&gt;</net>	Go to NET menu		
<setip 10.0.2.200=""> &lt;↓&gt;</setip>	Set the IP-address of the device		
<netmask 255.0.0.0=""> &lt;↓&gt;</netmask>	Set the subnet mask		
<gateway 10.0.0.101=""> &lt;↓&gt;</gateway>	Set the default gateway		
<m> &lt;&gt;</m>	Go to Configuration Management (CM)		
<m> &lt;&gt;</m>	Go to Main Menu		
2 <->>	Go to Fault and maintenance management (FMM)		
<apply all=""> &lt;↓&gt;</apply>	Apply all configurations (written in the running config.)		
<confirm> &lt;↓&gt;</confirm>	Confirm all configurations (written in the startup config.)		

In Menu Configuration Management (CM) you can type <CONFIG> to see the following picture:

CO\_CM>CONFIG Running Line Configuration xDSL. DST<sub>-</sub>1 DST<sub>2</sub>2 Master(HTU-C) Master(HTU-C) Mode : Extended rates: OFF OFF Line coding : PAM32 PAM32 Baserate 89 89 Annex В R Payload WAN WAN Clock source Int GS compatible : OFF NM threshold : OFF LA threshold : OFF

CO CM>

Enter in device 2 with the Monitor (LCT, RS-232) or Telnet interface.

Type following commands	Description		
3 <↓>	Go to Configuration Management (CM)		
<default everything=""> &lt;↓&gt;</default>	Set everything to default configuration		
<master 1="" off=""> &lt;↓&gt;</master>	Configure SHDSL 1 as SLAVE		
<master 2="" off=""> &lt;↓&gt;</master>	Configure SHDSL 2 as SLAVE		
<payload 1="" wan=""> &lt;↓&gt;</payload>	Configure Ethernet over SHDSL 1		
<payload 2="" wan=""> &lt;↓&gt;</payload>	Configure Ethernet over SHDSL 2		
<net> &lt;↓&gt;</net>	Go to NET menu		
<setip 10.0.2.201=""> &lt;↓&gt;</setip>	Set the IP-address of the device		
<netmask 255.0.0.0=""> &lt;↓&gt;</netmask>	Set the subnet mask		
<gateway 10.0.0.101=""> &lt;↓&gt;</gateway>	Set the default gateway		
<m> &lt;&gt;</m>	Go to Configuration Management (CM)		
<m> &lt;&gt;</m>	Go to Main Menu		
2 < 4>	Go to Fault and maintenance management (FMM)		
<apply all=""> &lt;↓&gt;</apply>	Apply all configurations (written in the running config.)		
<confirm> &lt;↓&gt;</confirm>	Confirm all configurations (written in the startup config.)		

In Menu Configuration Management (CM) you can type <CONFIG> to see the following picture:

CP\_CM>CONFIG Running Line Configuration xDSL DSL1 DSL2 Slave(HTU-R) Slave(HTU-R) Extended rates: OFF OFF Line coding : PAM32 Baserate : 89 PAM32 89 Annex : B В Payload WAN WAN Clock source : Int Int GS compatible : OFF NM threshold : OFF LA threshold : OFF

CP\_CM>

The idea is the following: the default settings help any device to be in an initial state, then the MASTER/SLAVE mode is enabled on the modem, then the transmit data is configured, then the network settings are configured (IP address, default subnet mask and default gateway) and finally, these settings are applied and then are written in the EEPROM.



#### **ATTENTION**

DON'T FORGET TO WRITE THE CONFIGURATION IN THE STARTUP CONFIGURATION WITH THE FOLLOWING COMMANDS:

## **Connector Description**

## **SHDSL Technical Specification**

Specification ITU-T G.991.2 G.shdsl and G.shdsl.bis
Line Code TC-PAM16/32, Extended: TC-PAM4/8/64/128

Impedance  $135\Omega$ 

Transmit Power 13.5 (Annex A) or 14.5 (Annex B) dBm @  $135\Omega$ 

Number of Pairs 2 or 4

Bit Rate 192 to 5704kbit/s, Extended: 128 to 15232kbit/s

Overvoltage Protection ITU-T Rec. K.20/K.21 Connector Type RJ-45 Female, 8 pin

## **Ethernet Technical Specification**

Standard: IEEE-802.3, VLAN/QoS IEEE-802.1q/p

Number of Interfaces

Data Rate 10/100BaseT, Full/Half Duplex Protocols Data, Telnet, SNMP, WEB

Signal Level Ethernet

MDI/MDI-X auto crossover Supported

Auto Negotiation Supported

Connector Type RJ45 Female, 8 pin

#### E1 (G.703) Technical Specification

Specification ETS 300 166, ITU-T Rec. G.703, G.704

Number of Interfaces 2 Line Code HDB3

Impedance either  $120\Omega$  or  $75\Omega$ 

Jitter ITU-T Rec. G.823, ETSI TS 101 135

 $\begin{array}{lll} \mbox{Bit Rate} & 2048 \mbox{kbit/s} \ \pm 50 \mbox{ ppm} \\ \mbox{ESD Protection} & 8 \mbox{kV (Air discharge)} \\ \mbox{Connector Type} & RJ45 \mbox{ Female, 8 pin} \end{array}$ 

## **Monitor/Local Craft Terminal Technical Specification**

Specification EIA-232 / V.28

Data Rate 9600 baud, asynchronous

Protocol 8 bit, no parity, 1 stop bit, no flowcontrol

no linefeed with carriage return

Signal Level V.28

Alarm Output Spec Load Driver

Max. Switching Voltage 60VDC

Max. Switching Current 150mA

Connector Type DB9 Female

# **Power Supply Technical Specification**

Specification ETSI ETS 300 132-2

Voltage 38-72VDC local power

Voltage (-24V models) 18-36VDC local power

Connector Type Molex Mini-Fit 39-01-2040

Power Consumption Typically 4/6 Watts if 2/4 DSL pairs

#### **SHDSL Connector Specification**

	Pin No	Description	
	1	NC (not used)	
	2	NC (not used)	
1 8	3	SHDSL interface B *	
	4	SHDSL interface A	
	5	SHDSL interface A	
	6	SHDSL interface B *	
	7	NC (not used)	
	8	NC (not used)	
	* only used in V54		

# **Ethernet Connector Specification**

	Pin No	Description
	1	Tx+ (transmit data)
1 8	2	Tx- (transmit data)
	3	Rx+ (receive data)
	4	NC (not used)
	5	NC (not used)
	6	Rx- (receive data)
	7	NC (not used)
	8	NC (not used)

## E1 (G.703) Connector Specification

	Pin No	Description	
	1	E1 Input → CH1/2 Wire A	
1 8	2	E1 Input → CH1/2 Wire B	
	3	NC (not used)	
	4	E1 Output → CH1/2 Wire A	
	5	E1 Output → CH1/2 Wire B	
	6	NC (not used)	
	7	NC (not used)	
	8	NC (not used)	


# **Monitor/LCT Connector Specification**

	-			
	Pin No	Description		
9	1	Urgent Alarm Output		
	2	TXD (Transmit Data)		
6 . 5	3	RXD (Receive Data)		
	4	NC (not used)		
# 🖫	5	SGND (Ground)		
(6° • 1	6	NC (not used)		
	7	NC (not used)		
$\bigcirc$	8	NC (not used)		
	9	Not Urgent Alarm Output		

# **Power Supply Connector Specification**

· onor ouppry connector opcomouncer				
	Pin No	Description		
<b>√ □ □ □ □ □ □ □ □ □ □</b>	1	Negative power terminal		
	2	Protection ground		
2	3	NC (not used)		
	4	Positive power terminal		

# **Panel Description**



Connector	LED	RED	GREEN	AMBER	OFF
xDSL 1 (DSL No 1)	Left	DSL not working	DSL normal operation		
xDSL 1 (DSL No 3, only on V54)	Right	DSL not working	DSL normal operation		
xDSL 2 (DSL No 2)	Left	DSL not working	DSL normal operation		
xDSL 2 (DSL No 4, only on V54)	Right	DSL not working	DSL normal operation		
G.703 1 or G.703 2	Left		E1 normal operation		Failure / no E1 Signal
G.703 1 or G.703 2	Right			E1 Alarm	E1 normal operation
Ethernet	Left		Blinking = Data		Connection not active
Ethernet	Right			100 Mbit/s data rate	10 Mbit/s data rate

# **Environment**, EMC and Safety

Storage: ETS 300 019-1-1 Class 1.2 (-25°C ... +55°C) Transportation: ETS 300 019-1-2 Class 2.3 (-40°C ... +70°C) Operation: ETS 300 019-1-3 Class 3.2 (-5°C ... +45°C) Higher Operation Temperature range available on request (-20 °C ... +80 °C)

DimensionI: 216(W)x165(D)x43(H) mm

Weight < 1.0kg in Metal DIN-Rail Enclosure

Standards: EN 300386 V1.4.1:2008 EN 61000-4-2/A2:2001

EN 50121-4:2006 EN 61000-4-3:2006 EN 60950-1:2006 EN 61000-4-4:2004 EN 55022:2006, Class B EN 61000-4-5:2006 EN 55024/A2:2003 EN 61000-4-6:2007 EN 61000-4-6/A1:2001

# **Available Models**

Ordering Code	Interfaces	Power Supply	Attention!
FG-PAM-RAIL2N-2E1B/Eth, V51	2xDSL 2xE1 1xETH	38-72VDC	
FG-PAM-RAIL2N-2E1B/Eth-24V, V51	2xDSL 2xE1 1xETH	18-36VDC	
FG-PAM-RAIL2N-Eth, V53	2xDSL 1xETH	38-72VDC	G.703 connector has no function
FG-PAM-RAIL2N-Eth-24V, V53	2xDSL 1xETH	18-36VDC	G.703 connector has no function
FG-PAM-RAIL4N-Eth, V54	4xDSL 1xETH	38-72VDC	G.703 connector has no function, xDSL connector has 2 DSL interfaces
FG-PAM-RAIL4N-Eth-24V, V54	4xDSL 1xETH	18-36VDC	G.703 connector has no function, xDSL connector has 2 DSL interfaces